

SOHNNE®

ASSEMBLY INSTRUCTION

CH25 Lounge Chair



Welcome Guide

www.sohnne.com

WELCOME

Getting Started

Your CH25 Lounge Chair arrives fully woven and ready to use — no tools required. A few simple habits will keep its solid-wood frame and hand-woven paper cord beautiful for decades.

READY TO USE

The chair may arrive partially assembled. Unpack it carefully and, if any fittings are supplied, hand-tighten them before first use. No power tools are needed.

PLACEMENT

Use on a level surface. Keep at least 12 in (30 cm) from heaters and out of direct sun to protect the wood and the natural paper cord.

USE

Sit normally. Avoid standing or jumping on the chair, and don't drag it across the floor — lift to reposition.

IN THE BOX

1 × CH25 Lounge Chair

MATERIALS

Solid wood · paper cord

WARRANTY

12-month manufacturer

SUPPORT

24/7 customer care

Care & Maintenance

Natural materials reward a little regular attention. Follow these steps to keep the weave taut and the frame rich in colour.



Paper cord weave

Dust weekly with a dry cloth or soft brush. Wipe spills immediately with a barely-damp cloth, then dry at once — never soak the cord. Avoid sharp objects that can snag the weave.




Solid wood frame

Dust weekly with a dry cloth, then apply a quality furniture wax or oil 2–3× per year to nourish the timber and even out its tone.



Hardware

Re-tighten any bolts after the first 2 weeks of use, then check every 6 months to keep every joint firm and silent.



SOHNNE®

@sohnne

SHARE · REVIEW · EARN

Worth sharing.

\$100

FOR A VIDEO REVIEW

\$50

FOR A PHOTO REVIEW

 Tag us @sohnne

www.sohnne.com