

SOHNNE®

ASSEMBLY INSTRUCTION

Chieftain Chair



Welcome Guide

www.sohnne.com

WELCOME

Getting Started

Your Chieftain Chair pairs a sculpted solid-wood frame with hand-upholstered leather. It arrives ready to use — no power tools required. A little routine care keeps the timber and leather beautiful for decades.

READY TO USE

The Chieftain Chair may arrive partially assembled. Unpack it carefully and, if any fittings are supplied, hand-tighten them before first use. No power tools are needed.

PLACEMENT

Use on a level surface. Keep at least 12 in (30 cm) from heaters and out of direct sun to protect both the leather and the wood.

USE

Sit normally and avoid standing or jumping on the chair. Lift to reposition rather than dragging it across the floor.

IN THE BOX

1 × Chieftain Chair

MATERIALS

Solid wood · leather

WARRANTY

12-month manufacturer

SUPPORT

24/7 customer care

Care & Maintenance

Fine leather and solid wood reward a little regular attention. Follow these steps to keep the upholstery supple and the frame rich in colour.



Leather cushions

Dust weekly and wipe with a slightly damp cloth, then dry immediately. Condition with a quality leather conditioner 2–3× per year and keep away from sharp objects.




Solid wood frame

Dust weekly with a damp cloth and dry at once, then apply furniture wax or oil 2–3× per year to nourish the timber and even out its tone.



Hardware

Re-tighten any bolts after the first 2 weeks of use, then check every 6 months to keep every joint firm and silent.



SOHNNE®

@sohnne

SHARE · REVIEW · EARN

Worth sharing.

\$100

FOR A VIDEO REVIEW

\$50

FOR A PHOTO REVIEW

 Tag us @sohnne

www.sohnne.com